



---

# EAGLE RENTAL<sup>TM</sup>

---

Stevens: 1327 N. Reading Road, 17578 - (717) 336-0777  
Lebanon: 2530 Quentin Road, 17042 - (717) 274-3945  
[www.eaglerentalcenter.com](http://www.eaglerentalcenter.com)

---



## Soup Warmer/Cooker - Operating Instructions

1. **Do Not Operate the Kettle Dry.** Place 26 oz. water in water bowl and add water as needed during cooking to maintain this level.
2. The temperature control on these kettles is a combination ON/OFF switch with an infinite control.
  1. If preheating is desired, set control at "HIGH" for approximately 20-30 minutes. Prolonged "HIGH" setting may result in overcooking or scorching.
  2. Set dial to number required to maintain desired temperature. Adjustment may be necessary because foods and liquids vary in density.
  3. Soup cookers are equipped with a warning light to prevent overheating or scorching. When the light is on, all electric current to elements will be off. Turn the heat setting down to a lower setting and wait 5-10 minutes for the light to go out. It is also advisable to check the water level in water bowl. Prolonged overheating on "HIGH" will boil the water out of the water bowl much quicker than at a lower setting.
  4. Turn the control to the "OFF" position when the unit is not in use. **Caution: Do Not Overheat the Unit.** If you do, it will take considerable time to cool to a proper temperature.

**Do Not Submerge Unit in Water at Any Time.** Change water in water bowl daily to remove any food collection that may have entered water bath. Clean soup bowl, cover and kettle at a sink with soap and water.

The exterior surfaces of warmer can be kept clean by washing with a soft cloth and milk soap and water. **Do not Use an Abrasive Cleaner** as the attractive coatings will be affected adversely.